

GryphonX[™] Micro Ducts Accessories

Air Blown Fibre Connectors





Connectors

Straight connectors used for external plant where gas sealing not required.

Permanent straight connector used for connection different diameter tubing for external plant where gas sealing not required. This is not removable, once fitted.

TYPE OF CONNECTOR					"Y" Connector
Part No.	CNT-01XX	CNT-02XX	CNT-03XX	CNT-04XX	CNT-05XX
Available Diameter (mm)	3/5/7/8	5/7/8	7	5	5



Gas & Water Blocking Connector

The gas and water blocking connector is used for prveenting gas migrating and blocking water entering the tube.

TYPE OF CONNECTOR				
Part No.	CNT-11XX	CNT-12XX	CNT-13XX	CNT-14XX
Available Diameter (mm)	5	5/7	5/7	5



Reducer Connectors

The reducer connector is used to joint different overall diameter microducts, can be used at external plant where gas sealing is not required.

TYPE OF CONNECTOR			Bulkhead Gas/Water Block Reducer	
Part No.	CNT-21XXYY		CNT-22XXYY	
Available Diameter (mm)	5-3/ 5-4/ 7-3//7-5/8-3/8-5/8-7/10-5		5-3/7-5/8-5/8-7	
TYPE OF CONNECTOR				
Part No.	CNT-23XXYY	CNT-24XXYY		CNT-25XXYY
Available Diameter (mm)	5-3/6-5/7-5	8-7		8-5



GryphonX[™] Micro Ducts Accessories

Air Blown Fibre Connectors





Tube End Stop

Tube end stop is used for external plant. Water, soild material, mud, sand, dirt or gas prevent. The internal tube end stop is for providing a gas tight seal to unpopulated tubes. Bulked connector plug used for sealing unused bulkhead connectors within internal plant

TYPE OF CONNECTOR			Bulkhead Connector Plug	
Part No.	CNT-31XX	CNT-32XX	CNT-33XX	
Available Diameter (mm)	3/5/7/8	5/7/8	7	



Cable Through End Cap Connector

The cable through end cap connector is used to prevent the dust or soil goes into the duct which already has the cable inside

TYPE OF CONNECTOR			
Part No.	CNT-06XX		
Available Diameter (mm)	5/8/10/12/14/16		

Notes:

1) XX = Duct diameter (05/5mm, 07/7mm, 08/8mm, 10/10mm, 12/12mm, 14/14mm, 16/16mm) 2) YY = Duct diameter for reducer (03/3mm, 04/4mm, 05/5mm..)